

PARTS LIST:

- 2x Shelf Platters
- 1x Chrome Shaft
- 1x Top Bracket
- 1x Base Bracket
- 1x Screw Kit
- 2x Thrust Bearings
- 1x Pin
- 1x Door Follower
- 1x Instruction Sheet

Assembly and Installation

1. Attach base bracket to bottom of cabinet with screws provided (Fig. 2).
2. Slide bottom shelf onto chrome shaft and slide to rest against base thrust bearing (Fig. 1).
3. Choose desired height for top shelf (three positions) and insert pin (Fig. 1).
4. Slide upper thrust bearing onto shaft (with pin location facing down), locate on pin (Fig. 1).
5. Slide top shelf into place (Fig. 1).
6. Fit complete assembly into bottom bracket. Ensure flat side of the base thrust bearing lines up flat on base plate (Fig. 2).
7. Locate top bracket onto shaft and attach to cabinet with screws (Fig. 2).
8. Attach door follower to door with screws provided. Ensure door follower does not run out of stroke with door in fully open or closed position (Fig. 2).

