



USING A HACKSAW, CUT LADDER TO THE CORRECT MEASUREMENT, FROM THE HINGE LINE, TO THE GROUND AND FIT PLASTIC FEET.



YOU CAN MAKE MINOR ADJUSTMENTS TO THE LADDER AFTER FITTING THE FEET.




KIMBERLEY[™]


www.kimprod.com.au

PH: 1800 225 377

Email: kimprod@kimprod.com.au


INSTALLATION INSTRUCTIONS FOR ALUMINIUM ATTIC LADDER
MODEL KASW45 / KASW46






FOR PACKING PURPOSES, THE DOOR KEY ROD IS SUPPLIED IN THE UNITS SPRING. REMOVE IT, AND STORE IT IN A SAFE PLACE.


MODEL KASWB40 CUT OUT SIZE IS 540MM X 1310MM. IT IS IMPORTANT TO CHECK THE FRAME SIZE BEFORE CUTTING THE HOLE!




MAKE A ROUGH OPENING IN THE CEILING, AS SHOWN ABOVE. IF THE LADDER IS WIDER THAN YOUR JOIST CENTRES, YOU SHOULD CONSULT AN STRUCTURAL ENGINEER FOR ADVICE.




THERE ARE 4 TEMPORARY SUPPORT STRAPS SUPPLIED WITH THIS LADDER. WHEN YOU ARE SATISFIED WITH THE POSITION OF THE LADDER, BEND THE STRAPS OVER THE CEILING JOISTS AND SECURE WITH LARGE HEAD NAILS.




WE RECOMMEND YOU USE SCREWS TO FIX THE LADDER INTO PLACE.



UNFOLDING DOWN THE LADDER.



ADJUST WHEN THE LADDER IS OPEN ONLY.



ADJUST OUTWARDS TO INCREASE CLEARANCE BETWEEN LADDER & HATCH DOOR.