

Please retain this sheet for future reference.

#### PARTS LIST:

- 1x Lid Bracket (SKRB07-02N)
- 1x Lid (SKRB07-01)
- 1x Bucket (SKRB06W)
- 1x Eye Hook (HW8)
- 1x Nylon Cord (HW14)
- 6x 8g x 1/2" panhead screws (HW33)
- 1x Instruction Sheet

#### Installation

1. Attach lid to clasps on lid bracket as per diagram at right. (Just above part number on lid bracket).
2. Establish desired position of bin. Allow clearance for lid movement.
3. Mark screw holes through bracket. Drill six 2mm holes. Ensure there is enough thickness on door panel so that drill and/or screws do not penetrate front surface. Fix bracket in place.
4. Position eye screw on inside of cabinet approx. in line with top of open lid. Feed nylon cord through hole in lid and tie knot. Tie other end to eye screw. Test lid movement with door.
5. Slide the bin body onto hangers as per diagram.

**Note:** Plastic liners may be used if desired.

### How To Care For Your New Kimberley Waste Bin

1. Please make sure you thoroughly read and understand the installation instructions and follow them carefully.
2. For best results and longevity, always use a bin liner inside your waste bin.
3. Always make sure the liner is fitted without obstructing any of the waste bins moving parts.
4. Do not overload your waste bin.
5. Do not push the rubbish down to try to compact your waste.
6. Do not place heavy items on top of the bin lid. There is a Wire Basket (KWB01) available to suit Waste Bin Models: KRB06, KRB06D, KRB08, KRB14, KRB14D, KRB15 & KRB15D.
7. Never try to close your waste bin with your feet.
8. Never force the waste bin closed.
9. Clean the interior and exterior of the waste bin regularly using a soft cloth and warm mild soapy water. Do not use harsh detergents.
10. Use a soft cloth to dry the waste bin after washing.
11. Thoroughly dry metal components to avoid rust and damage.
12. Do not use the bin outside or expose to the weather.
13. Do not place waste bin near a heater or hot device.

